

# GoldMaster®



## REVO-35 SES SİSTEMİ

## IMPORTANT SAFETY INFORMATION





### CAUTION ELECTRIC SHOCK HAZARD

- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Unplug the speakers from the computer and from the electrical outlet before cleaning them With a dry cloth.
- Install in accordance with the manufacturer's instructions.
- Place the speakers in a stable location so they will not fall causing damage to the speakers or bodily harm
- Do not use the speakers near water, and do not immerse them in any liquid or pour any liquid on them.
- Do not block the openings in the speaker cabinets, never push objects into speaker vents or slots because of fire or electric shock hazards, and provide sufficient space around the speakers for proper ventilation.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized plug. A polarized plug has two blades with one wider than the other. The wide blade is provided for your safety. If the provide plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Operate the speakers only from the low level audio line out jack of the computer or of an audio device.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- For added protection during lighting storms, unplug the speakers from the electrical outlet and turn off the computer.
- Unplug this apparatus when unused for long periods of time.
- Servicing is required when the apparatus has been damaged in any way, such as when the power-supply cord or plug has been damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- Refer all servicing to qualified service personnel.
- The speakers should be disconnected from the mains by placing the power/standby switch in the standby position and unplugging the power cord of the speakers from the AC mains receptacle.
- Do not place any form of open flame source, such as lighted candles, on the apparatus.
- The socket-outlet shall be installed near the equipment and shall be readily accessible.

#### WARNING:

**TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT EXPOSE THIS APPARATUS TO RAIN OR MOISTURE.**

Thank you for purchasing the Revo-35 speaker system from GOLDMASTER(R). Your Revo-35 speakers produce great sound and are easy to use. To discover more GOLDMASTER (R) Products, or if you have questions about your Revo-35 speaker, visit us on the web at [www.goldmaster.com.tr](http://www.goldmaster.com.tr)



## Setting up your GOLDMASTER REVO-35 speakers.

**Important: For your safety, set up the system before plugging it into a power source.**

1. Before attaching the cables to the subwoofer, position the two front satellite speakers on either side of your monitor. Depending on where you place your speakers, adjust them to direct the sound toward you. For best sound quality, place the subwoofer on the floor beneath your desk. Be sure to maintain at least 6 inches of spacing around the subwoofer to allow for adequate ventilation.


2. Connect the satellite speakers to the subwoofer as shown on the previous page.

3.A. If you have a PC:

Plug the audio input cable from the subwoofer into the speaker output on your PC (picture)

B. If you have a video game console (PlayStation<sup>®</sup>2, Xbox<sup>™</sup>, or GameCube<sup>®</sup>)

- Requires the Console Gaming Y-adapter (sold separately). Connect the red and white RCA cable that came with your console gaming system to the matching red and white RCA jacks on the Console.
- Gaming Y-adapter.  
Connect the 3.5 mm Stereo Cable connected with Subwoofer to the lime green input on the Console
- Gaming Y-Adapter.



C. If you have a DVD/VCD player:

- Requires a dual-RCA cable (normally provided with DVD/VCD player). Connect the red and white RCA Cable to the output Jacks on the players.
- Connect another end of Dual-RCA cable to the Audio input Jack on Subwoofer.

## Enjoying your GOLDMASTER REVO-35 speakers.

Access these controls

**Power On/off:** Located on the subwoofer, use to turn on/off the power with VFD display

**System Volume:** Located on the subwoofer and remote controller, Use to adjust the overall system volume.

**Subwoofer Volume:** Located on the subwoofer and remote controller. Use to adjust subwoofer Volume (bass level).

**XBASS:** Located on the remote controller. Use to get XBASS sound effort.

**Mute:** Located on the subwoofer and remote controller. Use to minimize the sound.

## Specifications

- Total RMS Power : 105Watts
  - Subwoofer : 30 Watts RMS into 4ohms at 100Hz at 10% THD (total harmonic distortion)
  - Satellites : 75Watts RMS(5x15w) into 4ohms at 1kHz at 10% THD(total harmonic distortion)
- Total Peak Power : 210Watts at<10% THD
- System THD : Better than 0.05% THD before clipping
- Signal to noise ratio : >85dB
- Frequency response : 20Hz-20kHz
- Driver Size : 3"+1.5" high excursion satellites, 5.25" high excursion subwoofer
- Speaker dimensions
  - Satellites : 90W\*135D\*250H(mm)
  - Subwoofer : 145W\*300D\*310H(mm)

## ÖNEMLİ GÜVENLİK BİLGİLERİ





### ELEKTRİK ŞOKU TEHLİKE UYARISI

- Lütfen talimatları okuyunuz ve saklayınız.
  - Uyarılara dikkat ediniz.
  - Tüm talimatları dikkate alınız.
  - Cihazı çalıştırmadan önce cihaz üzerinde oluşan tozlanmaları siliniz.
  - Üretici firmanın talimatları doğrultusunda bağlantılarını yapınız.
  - Hoparlörleri zarar gelmeyecek ve düşmeyecekleri uygun bir yere koyunuz.
  - Hoparlörleri suya yakın yerlerde kullanmayınız ve nemli ortamlarda bırakmayınız.
  - Hoparlör deliklerine herhangi bir cisim sokmayınız.
  - Elektrik çarpması riski doğabilir,ve uygun havalandırma şartları için hoparlörlerin çevresinde yeterli boş alan sağlayınız.
  - Kalorifer soba, gibi cihazların yakınında asla hoparlör sisteminizi kurmayınız.
  - Hoparlörleri sadece bilgisayarın veya ses aygıtının ses hattı çıkışından çalıştırınız.
  - Güç kablosunun ayak altında olmamasına dikkat ediniz
  - Sadece imalatçı tarafından verilen aksesuarları kullanınız.
  - Daha fazla koruma için hoparlörleri elektrik prizinden çıkarmadan önce bilgisayarınızı kapatınız
  - Sistem uzun zaman kullanılmıyacaksa. Lütfen enerji kablosunu prizden çıkartınız.
  - Herhangi bir yolla sistemin zarar görmesi, güç kaynağı kablosu veya fişinin zarar görmesi, sıvı dökülmesi veya cisimlerin içeri düşmesi, nem tutması cihazın normal çalışmasını veya bozulmasına neden olabilir.
  - Tüm bakım onarımının nitelikli personel tarafından yapılması önerilir.
  - Yanan mum gibi yanıcı kaynakları sisteme yaklaştırmayınız.
  - Priz sistemi, ses sisteminin yakınında olmalı ve kolay erişilebilir olmalıdır.
- Ürün tasarımı ve özellikleri bildirme gerek duymaksızın değiştirilebilir. Bu özelliklere ürün ana özellikleri yazılım, yazılım sürücülerini ve kullanım kılavuzu dahildir. Bu kullanım

### UYARI:

**ELEKTRİK ŞOKU RİSKİNİ AZAL TMAK İÇİN SİSTEMİ,  
YAĞMURLU YADA NEMLİ ORTAMLARDA AÇMAYINIZ.**

Goldmaster REVO-35 ses sistemini aldığınız için teşekkür ederiz. Tercih ettiğiniz cihazın kullanımı kolay ve ses kalitesi oldukça iyidir. Goldmaster'ı daha fazlası ile keşfetmek ya da ürün ile ilgili sorunlarınız için [www.goldmaster.com.tr](http://www.goldmaster.com.tr) sitemizi ziyaret ediniz.



## **GOLDMASTER REVO-3 ses sistemini kurmak:**

**Önemli: Güvenliğiniz için, elektrik prizine takmadan önce hoparlör sistemini kurunuz.**

1. Subwoofer bağlantılarını yapmadan önce, ön uydu hoparlörleri monitörün her iki yanına koyunuz. Sağ ön hoparlör sisteminiz için merkez kontrolü yapar, dolayısıyla onu kolay erişebileceğiniz bir yere koyunuz. Hoparlör sisteminizi nasıl kurduğunuza bağlı olarak, onları sesin size doğru gelebilecek şekilde yerleştiriniz. Gerçek ses kalitesi için, subwoofer'ı masanızın üzerine yerleştirebilirsiniz. Subwoofer'ın yeterli hava sirkülasyonu yapabilmesi için çevresin de yeterli boş alan olduğuna emin olunuz.

2. Uydu hoparlörleri bir öceki sayfada gösterildiği gibi bağlayınız.

3. A . Bilgisayarınız varsa :

Subwooferın ses giriş kablosunu bilgisayarın hoparlör çıkışına bağlayınız.

B. Eğer bir Video oyun consolu varsa (PlayStation2, Xbox(TM) ya da GameCube):


Bu konsol Y adaptörü gerektirmektedir. Oyun kablosu ile gelen RCA kablunun kırmızı ve beyaz uçlarını oyun konsolunun aynı renkli jacklarına takınız.

Oyun konsol Y adaptörü

3.5mm stereo kabloyu subwoofer ile bağlanmış yeşil giriş hattına bağlayınız

C- DVD yada VCD kullanıyorsanız

RCA kabloya ihtiyacınız vardır. Kırmızı ve beyaz kabloları cihazın çıkış jacklarına bağlayınız. diğer ucunu ise subwooferın ses giriş jackına takınız.



## **GOLDMASTER REVO-35 ses sistemi kullanımı**

### **Açma/Kapatma**

Açma/Kapama düğmesi Subwoofer üzerinde yer alır.

### **Ses kontrolü**

Subwoofer ve Uzaktan Kumanda üzerinde yer alır. Sistemin tüm ses kontrolünü ayarlar.

### **Subwoofer Ses kontrolü**

Subwoofer ve Uzaktan Kumanda üzerinden kontrolü yapılır ve Subwoofer'ın ses kontrolünü yapmak için kullanılır (bass düzeyi).

### **XBASS:**

Kumanda üzerinde yer alır. XBASS ses girişimi için kullanılır.

### **Sessiz:**

Kumanda ve subwoofer üzerinde bulunur, ses girişlerini kapatır.



## Teknik Özellikler

* Toplam Güç (RMS)	: 60 Watt
Subwoofer	: 30 Watt (RMS), 4Ω (100Hz), 10% THD (Toplam Harmonik Sapma)
Uydu hoparlör	: 75 Watt RMS (5 x 15 W), 4Ω (1kHz), 10% THD (Toplam Harmonik Sapma)
* Toplam Peak Güç	: 210 Watt (<10% THD)
* THD	: 0.05% den daha iyi
* Sinyal/Gürültü Oranı	: >85dB
* Frekans Aralığı	: 20Hz – 20kHz
Sürücü boyutları	: 3"+1.5" uydu hoparlör, 5.25" subwoofer
* Hoparlör Boyutları	
Uydu hoparlör	: 90W x 135D x 250H(mm)
Subwoofer	: 145W x 300D x 310 H (mm)

# GoldMaster®

Cihazın Kullanım Ömrü 10 Yıldır.

Üretici ve İthalatçı Firma

AYYILDIZ ELEKTRİKLİ EV EŞYALARI İMALAT VE PAZARLAMA

Adres: Halkalı Cad. No:228 Sefaköy-İstanbul-Türkiye

Fax:021216930224

Web: [www.goldmaster.com.tr](http://www.goldmaster.com.tr) E-mail: [info@goldmaster.com.tr](mailto:info@goldmaster.com.tr)